# CCS Debug with IWRL6432

Feb. 2023



#### Setup

- Follow <u>SDK documentation to install CCS</u>
- For CCS v12.1 or older, there are several firsttime setup steps which must be completed in order for the xwrl6432 device to be recognized in CCS. These steps are listed in the <u>Pre-requisites</u> <u>To Detect Low Power Radar Devices in CCS</u> section of the SDK documentation.
  - For CCS v12.2 and on these steps are not required
- Ensure the EVM is configured for **Debug Mode** as specified <u>here</u>
  - S1.1 = ON, S1.2 = ON, S1.6 = OFF, S4.1 = OFF




#### **Execute the Demo in CCS Debug Mode**

 CCS, go to the **Debug** view and in the **Target Configurations** window under User **Defined** right click on **xwrl6432\_xds110.ccxml** and select **Launch** Selected Configuration




 If you do not see a target configuration file (.ccxml), follow the steps in the <u>Create Target Configuration</u> section of the SDK documentation

In the Debug window, right click and select Show all cores



Expand the Non Debuggable Devices. Right click on Texas Instruments
XDS110 USB Debug Probe\_0/CS\_DAP\_0 and select Connect Target



 Click on Scripts at the top and select LPRADAR wakeup gel → sop\_debug\_setup. The console should read "M4 reset released"




- If you do not see the script in the menu when the DAP is selected then you must add it to your target configuration file
  - Double-click on the target configuration file to edit
  - At the bottom select the Advanced tab. Under All Connections, select CS\_DAP\_0
  - For the initialization script, click Browse and navigate to the GEL file located at <SDK\_INSTALL>/tools/gelfile/xwrLx432.gel
  - Save the target configuration file



6


Right-click on Texas Instruments XDS110 USB Debug
Probe\_0/Cortex\_M4\_0 in the debug window and select Connect Target. Do a CPU reset on the m4 (ctrl+shift+r)




7

To load the demo code onto the device, click on Run at the top and select Load


 → Load Program... and browse for the .out file located at
 <CCS\_WORKSPACE>/ motion\_and\_presence\_detection\_demo\_xwrL64xx evm\_m4fss0-0\_freertos\_ti-arm-clang/<PROFILE>.



• Once the program is loaded the rfs binary must be loaded into memory before running the demo. In the toolbar click on **Tools** → **Load Memory**.





- In the window that opens, for File Type select Binary. Click Browse and navigate to the rfs binary at:
  <SDK\_INSTALL>\firmware\mmwave\_dfp\rfsfirmware\xWRL6432\mmwave\_rfs.b in. Click Next.
- In the Start Address box, enter: 0x21208000. Click Finish.



10

- To run the demo, click Run at the top then select Resume.
- The console should read "CLI is Operational"





• From this point you can send the configuration file (.cfg) over UART (using the GUI, terminal emulator, etc...) and the device will begin chirping