


Portable Projects – Linked Files


Link your file to the project using the variable via 'New->File':






Portable Projects – Linked Files

- The project will reference the linked file using the Linked Path variable, instead of an absolute path
- Looking at the file properties for the linked source file will show that is using the Linked Path variable










Portable Projects – Automated Definition of Linked Path Variables

- Use 'macro.ini' files to enable auto-definition of Linked Path variables on project import into another workspace
 - When a project is being imported (via Import Wizard) and a macros.ini is found in the root project location, it will auto-add any variables defined in the file to the Linked Resources list
 - TIP: Relative paths are supported in the 'macro.ini' file








Portable Projects – Environment Variables Macros

- Avoid absolute paths in the build options by using Environment Variables and Macros
- Every project automatically defines a number of different macros that can be used in build options







Portable Projects – Using Macros

- There are Configuration and Project level macros
 - User may also define their own macros similarly to how linked resource path variables are defined

