



# Stellaris Serial flash loader, Boot loader, LM Flash programmer

# StellarisWare™ In-System Programming Options


## Stellaris Serial Flash Loader

- Small piece of code that allows programming of the flash without the need for a debugger interface.
- All Stellaris MCUs ship with this pre-loaded in flash memory
- Interface options include UART or SSI
- Luminary Micro supplies a Windows™ application (GUI or command line) that makes full use of all commands supported by the serial flash loader (LMflash.exe)
- See application note [AN01242](#)


0xFFFFFFFF

0x000000800

0x000000000



# SSI and UART connections



Only UART0 support serial flash loader

# Command Definitions

- **COMMAND\_PING (0x20)**
  - Simply accepts the command and sets the global status to success.
- **COMMAND\_GET\_STATUS (0x23)**
  - Returns the status of the last command that was issued
- **COMMAND\_DOWNLOAD (0x21)**
  - Sent to the flash loader to indicate where to store data and how many bytes to send with the COMMAND\_SEND\_DATA commands that follow
- **COMMAND\_SEND\_DATA (0x24)**
  - Should only follow a COMMAND\_DOWNLOAD command
- **COMMAND\_RUN (0x22)**
  - Tells the flash loader to execute from the address passed as the parameter in this command.
- **COMMAND\_RESET (0x25)**
  - Tells the flash loader device to reset

## User application

- The first is to completely overwrite the flash loader with a new application.
- The second method involves programming the application to an address not used by the flash loader(0x800 or later), and then executing this application by issuing a “run” command.

# Serial flash loader binary file

- Download the binary file **serial\_flash\_loader.bin** which pre-loaded in flash before factory from web side:

[https://www.luminarmicro.com/products/software\\_updates.html](https://www.luminarmicro.com/products/software_updates.html)

Home ▶ Products ▶ Software Updates



The screenshot shows the 'Software Updates' section of the Luminarmicro website. On the left, a sidebar lists various product categories. The main content area is titled 'Software Updates' and contains a sub-header 'Utilities'. A table lists several software packages, with the 'Serial Flash Loader-00' entry circled in red. The table columns are: Product, Doc number, Description, Date, and Download. The 'Serial Flash Loader-00' entry has a red circle around it, and the 'download' button for that row is also circled in red.


Product	Doc number	Description	Date	Download
All	LMFlashProgrammer-923	GUI and command line flash programmer	12/17/09	<a href="#">download</a>
All	Serial Flash Loader-00	Serial Flash Loader	01/07/09	<a href="#">download</a>
Keil uVision	LMIDK-AGDI-33	Keil debug interface DLL for Stellaris ICDI	12/11/09	<a href="#">download</a>

- Re-program this binary file to the device by LM flash programmer to do the testing(use on-chip Serial Flash Loader to download user code)

# Stellaris® Flash Programming GUI

- **LM Flash Programming GUI**

- Simple graphical user interface
- Support for all Evaluation Kits
- Key features include:
  - Program
  - Verify
  - Erase
  - Read memory
- Available now




# Reprogram device

Reprogram the device with `serial_flash_loader.bin`, which locate at  
C:\StellarisWare\Serial Flash Loader\serial\_flash\_loader.bin


Select  
Manual  
Configuration

JTAG ICDI



## Reprogram device(cnt)

Select the  
binary file



## Use pre-load serial flash loader to download user code


Download user code to flash via pre-load serial flash loader, just like the device with factory default.

COM2?  
Select Serial(UART)

Auto baud rate


Transfer size=60

\*Use device manager  
to check your visual  
COM port



## Use pre-load serial flash loader to download(cnt)

Select your user code to download



Address will start from 0x00.




## Sflash utility

- The sflash utility that we provide in  
C:\StellarisWare\Serial Flash Loader\sflash.exe
- Usage:  
>sflash test.bin -p 0x00 -r 0x00 -c 1  
-p [program address]  
-r [execution address]  
-c [COM port number]


# Stellaris Boot Loader

- Small piece of code that can be programmed at the beginning of flash to act as an application loader
- Also used as an update mechanism for an application running on a Stellaris microcontroller.
- Interface options include UART (default), I<sup>2</sup>C, SSI, Ethernet, USB
- Included in the Stellaris Peripheral Driver Library with full applications examples
- See application note [AN01248](#)
- Preloaded in ROM on select Stellaris

# Stellaris Memory map



# Boot loader running procedure



# User Applications

- On the Stellaris microcontrollers, minimum size of a flash block is 1024-byte, this is a 1024-byte boundary,
- The boot loader at least need one flash block, so it requires that the application start at offset 2048 (0x0800) or more into the flash.

# Connection interface

- UART0 (default)
- I<sup>2</sup>C
- SSI
- Ethernet
- USB(DFU)

# Boot loader file

## File Name

bl\_startup\_ewarm.S

bl\_config.h

bl\_config.c

bl\_commands.h

bl\_packet.h

bl\_packet.c

bl\_enet.c

bl\_uart.h

bl\_uart.c

bl\_autobaud.h

bl\_ssi.h

bl\_ssi.c

bl\_i2c.h

bl\_i2c.c

bl\_usb.c

bl\_check.h

bl\_check.c

bl\_main.c

## Description

Boot Loader start code

Define Boot Loader option

Define Updater command

Serial data receive/transmit control

Ethernet data transmit

UART data transmit

SSI data transmit

I2C data transmit

USB data transmit

Check Updater condition

Updater main

## Definition in Bl\_config

- CRYSTAL\_FREQ Define crystal frequency for BootLoader
- APP\_START\_ADDRESS Define Application start Address
- FLASH\_RSVD\_SPACE Define Flash reserve size
- STACK\_SIZE Define BootLoader stack
- BUFFER\_SIZE Define BootLoader data receive buffer
- ENABLE\_BL\_UPDATE Enables updates to the boot loader
- FLASH\_CODE\_PROTECTION Flash code protection,erase the entire flash
- ENABLE\_DECRYPTION Enables the call to decrypt
- ENABLE\_UPDATE\_CHECK Check Updater condition
- FORCED\_UPDATE\_PERIPH Forced Updater check for GPIO module

## Definition in BI\_config

- FORCED\_UPDATE\_PORT      Forced Updater check for GPIO base address
- FORCED\_UPDATE\_PIN      Forced Updater check for GPIO pin
- FORCED\_UPDATE\_POLARITY      Define the polarity of the GPIO pin that results in a forced update
- UART\_ENABLE\_UPDATE      Enable UART to update Flash
- UART\_AUTOBAUD      Enable auto baud
- UART\_FIXED\_BAUDRATE      Define fixed baud
- SSI\_ENABLE\_UPDATE      Enable UART to update Flash
- I2C\_ENABLE\_UPDATE      Enable I2C to update Flash
- ENET\_ENABLE\_UPDATE      Enable Ethernet to update Flash


## BI\_config.h

C:\Stellarisware\boards\ek-lm3s8962\boot\_serial

- #ifndef \_\_BL\_CONFIG\_H\_\_
- #define \_\_BL\_CONFIG\_H\_\_
- #define CRYSTAL\_FREQ 8000000
- #define APP\_START\_ADDRESS 0x1000
- #define STACK\_SIZE 48
- #define BUFFER\_SIZE 20
- #define UART\_ENABLE\_UPDATE
- #define UART\_FIXED\_BAUDRATE 115200


## Download user boot loader(serial) to flash

1. You could recompile the boot\_serial project to get the binary file
2. Locate at C:\Stellarisware\boards\ek-lm3s8962\boot\_serial




## Download user boot loader to flash(cnt)

- Select the user boot loader file from  
C:\Stellarisware\boards\ek-lm3s8962\boot\_serial




## Program user code via user boot loader with UART0

- User code locate at C:\Stellarisware\boards\ek-lm3s8962\boot\_demo1



## Program user code via user boot loader with UART0 (cnt)


- You could recompile the boot\_demo1 project to get the binary file
- Locate at C:\Stellarisware\boards\ek-lm3s8962\boot\_demo1



# Download user boot loader(Ethernet) to flash


- Import the examples for the EK-LM3S8962
- C:\Stellarisware\boards\ek-lm3s8962\boot\_eth

*The boot\_eth is a small piece of code that can be programmed at the beginning of flash to act as an application loader as well as an update mechanism for an application running on a Stellaris Microcontroller.*




# Download boot\_eth.bin via LM Flash programmer

- You could recompile the boot\_eth project to get the binary file
- Locate at C:\Stellarisware\boards\ek-lm3s8962\boot\_eth




# Get current board MAC address


Select ICDI



Get current  
MAC address




# Configure your PC to static IP



# Configure the Client IP,MAC address

Configure Client  
IP,MAC address



## Download user code via Ethernet

- You could recompile the boot\_demo1 project to get the binary file
- Locate at C:\Stellarisware\boards\ek-lm3s8962\boot\_demo1

Select user code

